

SI5322B



Product Family Built-in type Dimensions Power supply Type EAN code Hob Ultra-low profile 30 cm Electric Induction 8017709193386



Aesthetics

DIGI	
Aesthetic	Universale
Colour	Black
Finishing	Glass
Material	Glass
Glass type	Ceramic
Glass edge	Angled edge
Type of control setting	Digi Touch
LED colours	Red
Control knob position	Front
Serigraphy colour	Grey

Programme / Functions

1	
(Ρ.
1	• /

Total no. of cook zones	2
No. of induction cook zones	2
No. of cooking zones with booster	2
Main on/off switch	Yes
Power levels	9

Options



490x270 mm

Residual time indicator Yes



End cooking timer	2	Control Lock / Child	Yes
Minute minder	1	Safety	
End of cooking alarm	Yes	Quick start	Yes

Technical Features



Front-centre - Induction - Single - 1.30 kW - Booster 1.40 kW - Ø 16.0 cm Rear-centre - Induction - Single - 2.30 kW - Booster 3.00 kW - Ø 21.0 cm

Automatic setting according to pan	Yes	Automatic switch off when overheat	Yes
dimension		Residual heat indicator	Yes
pan detection	Yes	Protection against	Yes
Minimum pan diameter indication	Yes	accidental start up	

Electrical Connection

Electrical connection rating (W)	3500 W	Type of electric cable installed	Yes, Single phase
Current	16 A	Frequency (Hz)	50/60 Hz
Voltage (V)	220-240 V	Power supply cable length	120 cm





Not included accessories



SCRP

Non-scratch hob scraper - suitable for induction and ceramic hobs



TPK Stainless steel grill plate to cook Teppanyaki dishes



Symbols glossary (TT)

P	Power booster: option allows the zone to work at full power when very intense cooking is necessary.		Ultra-low profile: Installation of product with flat edge - height of 1 mm.
ს	Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.	DIGI	Touch control
STOP ℃∓	Overheat protection: The safety system that automatically turns off the hob in case of overheating of the control unit.		Induction: The work of these hobs is based on the principle of electromagnetic induction. The heat is generated directly in the bottom of the pan during its contact with the hob.
4	Quick Start function: the chosen temperature is reached faster. The heating element works at maximum power until the right temperature is reached.	}-1	Indication of residual heat: After the glass ceramic hob is switched off the residual heat indicator shows which of the heating zones still remains hot. When the temperature drops below 60 ° C, the indicator goes out.
\odot	Time elapsed: shows how long the cooking zone has been in use.	\bigcirc	Timer: All ceramic hobs have a timer which automatically ends cooking after a preset time.